




# Simply Pay Getting Started Guide

## Simply Pay® : Laundry

I thank you for choosing Simply Pay®, the innovative payment and loyalty solution developed by LM Control. To ensure a successful Simply Pay® launch, we recommend that you follow this guide step by step.

The activation of Simply Pay® on your terminal is confirmed by the appearance of an additional button called Loyalty and a QR code.





# 1. Reload Levels & Bonus Settings

Reload levels and bonus amounts must be customized via the programming menu of your Touch'N Pay® terminal.

## 1. Access to the Programming Menu

Press and hold the “question mark” icon on the Home screen for at least 10 seconds, then release.



Enter your access code.




The default code is: **\*#69330#\***

If it has not been changed, it is important to modify it promptly for security reasons. To change the code, follow the instructions on page No. 3.

## 2. Main Programming Page

To access the next page containing the various configuration menus, simply press the SETTINGS button.



### Access Code Modification

Select the “Infos” tab



## Configuration of Reload Levels and Associated Bonuses

Select the “Parameter” tab, then “Cashless”.

Selections	Infos	Parametre	Réseau	Alerte	Jours spéciaux	Relevé d'information
Monnayeur	Lecteur de billet	Cashless	MENU			
Palier 1	2000	Bonus 1	200			
Palier 2	3000	Bonus 2	300			
Palier 3	5000	Bonus 3	575			
Cents						
<input checked="" type="checkbox"/> Appuie stop obligatoire rechargement						

Reload levels and bonuses must be entered in euro cents:  
€1 = 100 cents

Example :

From 2000cts to 2900.99cts reloaded= Bonus 200cts

From 3000cts to 4900.99cts reloaded= Bonus 300cts

From 5000cts reloaded= Bonus 575cts

**If your reload level exceeds €25 (2500 cents), do not forget to modify the maximum credit.**

For example, if you want a reload level of €100, you must enter:


Maximum credit: 10,000 cents

A value must be entered (do not leave it at 0 or blank).

Crédit max	10000	Cents
<input type="checkbox"/>	Vente forcée	
<input type="checkbox"/>	Présélection	




To validate all your settings, it is mandatory to click on “Apply all and reboot”, located at the bottom-right of the screen.



## 2. GAD – Simply Pay Configuration Center

Go to your GAD web portal to configure Simply Pay.

From the Simply Pay (1) tab → Configuration (2) → click on the gear icon of the terminal of your choice (3).




### Park Management



By default, all features of the selected terminal are enabled.

Uncheck the features you do not wish to offer to your customers.

- Online reload will be visible but disabled (greyed out).
- The machine reservation option will not be visible.



## Selection of Reservable Machines

Time during which a machine can be reserved: 10 minutes or 15 minutes.

If a user makes a reservation but does not use it within the allotted time, they will not be able to reserve another machine for the rest of the day.




## Billing Address Setup

The receipt is automatically generated whenever a Simply Pay wallet reload is carried out.



**Avoid "INVOICE ERROR"**

Complete the BILLING ADDRESS now; otherwise, your customers will receive an error message in the Simply Pay application and will not be able to retrieve their invoice.




## Park Management



## Promotions and Targeted Communications

- Without group management, by default, customers have access to all your laundries and all your terminals using Simply Pay.
- By configuring groups, a customer who scans a terminal belonging to a group will have access to all terminals within that group.




## IZLYPAY

IZLYPAY is the payment solution used by CROUS for students. It allows them to pay directly using their Izly wallet.

## Payment Methods

### Configuration required if the “Online Reload” option is enabled



The screenshot shows the 'Centre de Configuration Simply Pay®' interface. The navigation menu includes ACCUEIL, ÉVÈNEMENTS, CLIENTS, MARKETING, SUPPORT, and CONFIGURATION. The current page is 'MOYENS DE PAIEMENT' under 'GESTION DES GROUPES'. The main content area is titled 'Mes moyens de paiement disponibles' and shows two active options: 'CB/Esp' and 'E-commerce'. Below this is a section for 'Configurer les montants des rechargements en ligne + bonus (facultatif)'. It includes a sub-header and a description: 'On vous propose 4 paliers de rechargement avec la possibilité d'ajouter un bonus. Ces paliers seront visibles dans l'application Simply Pay® pour le client au moment de la demande de rechargement en ligne.' The configuration table has four rows, each with a 'Montant du rechargement' field and a 'Montant du bonus' field, both with a Euro symbol (€) and a text input field. A 'SAUVEGARDER' button is located at the bottom right of the configuration area.

In addition to reloading at the Touch’N Pay terminal, you can offer customers the option to reload their loyalty account online.

**To activate this feature, you must sign a specific acquiring contract with your bank.  
Please contact us at: [marketing@lmcontrol.fr](mailto:marketing@lmcontrol.fr)**


Once online reload is activated, you can configure your 4 reload levels and their associated bonuses.

### 3. GAD : Marketing Simply Pay

#### Available Promotions:

Two promotions can be activated:

- Welcome Offer
- Tie-in sale



#### Welcome Offer:

During their first reload, users may receive a bonus.

You choose:

- The minimum reload amount required to receive the bonus.
- The promotion start date and end date.

#### Tie-in sale:

You prioritize customers who use multiple services within the laundry.

After an initial purchase, the user receives a discount on a second purchase made within a defined time period.

Example:

With bundled sales, a Simply Pay customer who uses a washing machine and then a dryer will pay less for the dryer than a customer who only uses the dryer.